

# ABSORLINER

## SUPERIOR MOISTURE CONTROL FOR MOIST CONTAINERIZED CARGO

### HOW IT WORKS

ABSORLINER offers very fast absorption combined with high wet strength. In case of a rapid super-saturation event that produces water droplets on container ceiling and walls, ABSORLINER is designed to absorb that water—preventing it from falling as “container rain” on cargo. ABSORLINER then gradually releases this trapped water as moisture that can be collected and contained by ABSORBAG®, ABSOR-TOP® or ABSORPOLE®.



### UNIQUE FEATURES

- ❑ ABSORLINER is specially formulated with significant wet strength to support the absorbed moisture. It will not tear or fall off the ceiling.
- ❑ Protects cargo from “container rain” that appears as ceiling condensation that drips down onto the cargo.
- ❑ **One** roll of ABSORLINER will cover the ceiling of **eight**, 20' ISO containers.
- ❑ Can also be used on the walls to further protect moisture sensitive cargo.
- ❑ Installed with double-sided acrylic tape.

### CARGO APPLICATION

For added moisture control with moist cargoes, typically agricultural commodities such as coffee, cocoa, peanuts, beans and sugar.

### CARGO LOAD CONFIGURATION

Ceiling-mounted inside 20 ft or 40 ft containers with double-sided acrylic tape.

### PRODUCT SPECIFICATIONS

#### ABSORLINER

<u>PRODUCT #</u>	<u>Width</u>	<u>Length</u>	<u>Roll Weight</u>	<u># Per Pallet</u>
1403	45"	350'	70 lbs.	10

#### Acrylic Tape

<u>PRODUCT #</u>	<u>Width</u>	<u>Length</u>	<u>Case Weight</u>	<u>Ro. Per Case</u>
1402	3"	60 yd./Roll	15 lbs.	12

### Collection Capacity

20' container: approximately 6.5 liters of water

40' container: approximately 13 liters of water

### Disposal

100% recyclable

### How to Install

(See Other Side)

# HOW TO INSTALL THE ABSORLINER



1 Apply adhesive transfer tape on every 4th roof rib across the width of the container. Make sure the area to be taped is free from dust and other contaminants so that adhesive tape will stick.



2 Smooth tape with light pressure.



3 Remove tape liner to expose the adhesive film.



4 Roll out ABSORLINER on one side of container floor and cut to length.



5 Attach ABSORLINER to one side of the ceiling. Start at nose of container and work to doors.



6 Repeat steps 5 and 6 on the other side of ceiling.

**NOTE: Keep ABSORLINER as smooth as possible as you install it to the ceiling. This will prevent sagging. A slight gap in the center seam is normal.**

**BUFFERS USA™** 

*Securing Your Containers. Protecting Your Cargo.*

**Buffers USA Inc.  
10180 New Berlin Road  
Jacksonville, Florida 32226**

**Tel: 904-696-0010  
Fax: 904-696-0019**

**Email: [sales@buffersusa.com](mailto:sales@buffersusa.com)  
[www.buffersusa.com](http://www.buffersusa.com)**