



AbsorLiner™

INSTALLATION INSTRUCTIONS

1. Prepare surface by removing any dust, paint flakes, oil, water or any other contaminants so that adhesive tape will stick.
2. Apply adhesive transfer tape on every 4th roof bow across the width of the container.
3. Smooth tape with light pressure.
4. Remove tape liner to expose the adhesive film.
5. Roll out AbsorLiner™ on one side of container floor and cut to length.
6. Attach AbsorLiner™ to one side of the ceiling. Start at nose of container and work to doors.
7. Repeat steps 5 and 6 on the other side of ceiling.

NOTE: Keep AbsorLiner™ as smooth as possible as you install it to the ceiling. This will prevent sagging.

A slight gap in the center seam is normal.

