BUFFERS USA, INC. 10180 New Berlin Rd. Jacksonville, FL. 32226

(904) 696-0010 FAX (904) 696-0019 e-mail sales@buffersusa.com "The Intermodal Hardware Specialists"

ABSORPOLE[®] INSTALLATION INSTRUCTIONS

D

1 Pull out the Absorber from the Container, by pulling at the Hook.

2 Break off the Double Pin that is attached to the Hook.

3 Align the two holes of the Absorber and the Container

4 Push the Double Pin through the holes from the back – ALL THE WAY.

5 Pull hard on the Absorber to ensure that the Double Pin is securely locked.

6 Place the hook over a bar or loop near the ceiling and pull down until the hook snaps into position.

7 Push the Absorpole into the wall corrugation.











ABSORPOLE[®] AUTHORIZED REGIONAL CENTER WESTERN HEMISPHERE