

**MODEL 1402-2340**

**Wabash style**

**MODEL 1402-2340-SS**

**Wabash style**

**SUB FOR:** WABASH 06300297,  
PENZ 65-06, FLEET ENGINEERS 023-00669

**MATERIAL:** FAB. STEEL **FINISH:** ZINC-PLATED

**WEIGHT:** 0.52 LBS / 0.24 Kg

**SUB FOR:** FLEET ENGINEERS 021-00308

**MATERIAL:** STAINLESS STEEL

**FINISH:** SELF-COLOR

**WEIGHT:** 0.52 LBS / 0.24 Kg

**MODEL 1402-2350**

**Fruehauf style**

**SUB FOR:** FRUEHAUF WCF-3981-1, PENZ 65-04

**MATERIAL:** FAB. STEEL **FINISH:** ZINC-PLATED

**WEIGHT:** 0.45 LBS / 0.2 Kg

**MODEL 1402-2393**

**Miner style**

**SUB FOR:** MINER HB-1156-6,  
PENZ 65-05, FLEET ENGINEERS 023-00664

**MATERIAL:** FAB. STEEL **FINISH:** ZINC-PLATED

**WEIGHT:** 0.6 LBS / 0.27 Kg

**MODEL 1402-7247**

**Fruehauf style**

**SUB FOR:** FLEET ENGINEERS 023-00674

**MATERIAL:** FAB. STEEL **FINISH:** ZINC-PLATED

**WEIGHT:** 0.78 LBS / 0.354 Kg

**MODEL 1402-7531**

**Fruehauf style**

**SUB FOR:** FLEET ENGINEERS 023-00675

**MATERIAL:** FAB. STEEL **FINISH:** ZINC-PLATED

**WEIGHT:** 0.5 LBS / 0.226 Kg



# SWING DOOR HARDWARE

## HINGE BRACKETS

### DRY & REEFER VAN TRAILERS

**MODEL 1402-7532**  
**Trailmobile style**

**SUB FOR:** FLEET ENGINEERS 023-00678  
**MATERIAL:** FAB. STEEL **FINISH:** ZINC-PLATED  
**WEIGHT:** 0.54 LBS / 0.25 Kg

**MODEL 1402-7538**  
**Dorsey style**

**SUB FOR:** FLEET ENGINEERS 023-00662  
**MATERIAL:** FAB. STEEL **FINISH:** ZINC-PLATED  
**WEIGHT:** 0.6 LBS / 0.27 Kg

**MODEL 1402-9011**  
**Kentucky style**  
Bolt-on

**SUB FOR:** KENTUCKY 6650000003, EBERHARD 31-5897-1-13  
**WORKS WITH:** BUFFERS 1402-9007 HINGE **MATERIAL:** STEEL  
**FINISH:** HOT-DIP GALVANIZED **WEIGHT:** 1.53 LBS / 0.61 Kg

